



MISTRAL USER MANUAL

****Important Safety Information****

1. **Read the Manual:** Before using this equipment, carefully read the user manual provided. Familiarise yourself with its features, functions, and safety precautions.
2. **Power Supply:** Ensure that the equipment is connected to a properly grounded power source. Only use power supply with the specified voltage and current ratings. Avoid overloading power outlets or using extension cords excessively.
3. **Inspect Regularly:** Periodically inspect the equipment for signs of wear, damage, or worn cables. If you notice any issues, discontinue use immediately and seek professional assistance.
4. **Avoid Water Exposure:** Keep the equipment away from water, moisture, and damp environments. Do not operate it with wet hands.
5. **Unplug During Maintenance:** Always unplug the equipment before cleaning, servicing, or performing maintenance.
6. **Overheating:** If the equipment becomes unusually hot during operation, turn it off and allow it to cool down. Prolonged overheating can lead to malfunction or fire.
7. **Child Safety:** Keep electrical equipment out of reach of children. Children should not operate or tamper with it without adult supervision.
8. **Emergency Situations:** In case of smoke, sparks, or unusual odours, disconnect the equipment immediately and contact a qualified electrician.
11. **Authorized Repairs:** Do not attempt to repair the equipment yourself. Seek professional repair services from authorized technicians.
12. **Disposal:** Dispose of old or malfunctioning electrical equipment properly. Follow local regulations for recycling or disposal.

Remember that safety is important. If you have any doubts or encounter issues, consult us or a certified electrician.

OPERATING INSTRUCTIONS

Installation requirements

240 V single phase power source.

01

Before installation or servicing, turn off the unit, preferably switching off at power source.

02

Open the unit door using the dedicated key (turn to right)

03

Remove Vapour Gel container

04

Remove lid if it is on

05

Remove any used Gel residue and rinse container

06

Wipe out unit if necessary





07 Fill container to desired level with Vapour Gel

08 Replace container back into Mistral Unit (lid can be placed under the container)

09 Lid can be placed onto container if not using immediately

10 Close unit with key (turn to left)

11 Connect power supply to unit, plug into wall socket and switch on

12 Switch on and set fan speed to desired level by turning control knob to the right.

NeuSolutions

Specifications are subject to change without notice.
Copy or reproduction without permission is prohibited
www.neusolutions.com.au
All Rights Reserved.